

EXTERIOR PANEL KIT FOR BUILT-IN INSTALLATION WITH FREE OUTLET LC0578/LC0582 AND LC0692/LC0696

This instruction is an integral part of the booklet of the appliance on which the KIT is installed. Please consult this booklet for GENERAL WARNINGS and FUNDAMENTAL SAFETY RULES.


All the operations must be performed by qualified personnel using the required PERSONAL PROTECTIVE EQUIPMENT.

This kit can be installed in either a VERTICAL POSITION WITH FREE HORIZONTAL OUTLET or in a HORIZONTAL POSITION WITH FREE VERTICAL OUTLET (just for SLI). For installations in a HORIZONTAL POSITION WITH DUCTED OUTLET, an EXTERIOR PANEL KIT FOR BUILT-IN CEILING INSTALLATION WITH DUCTED OUTLET LC0618/LC0622 must be purchased.

Before installing the device, check that all necessary water and electrical connections have been set up inside the metal structure.

INSTALLATION OF DEVICE:

- Apply the 3 insulating panels supplied with the kit to the upper part of the device;




- Make 4 holes Ø 8mm in line with the **B** openings and insert the toggle bolts (2 for each bracket) into the wall;

 Install the 2 supporting brackets supplied with the device using the screws and washers supplied with the toggle bolts;

- Check that the brackets are properly secured by manually shifting them from left to right, up and down;
- Check that the brackets are firmly secured by shifting them manually from left to right, up and down;


<u>^•</u>

For the horizontal ceiling version, secure the device through the 2 "A" holes using the screws and washers supplied with the toggle bolts.




Before assembling the kit, the GRILL, FILTER-STOPPER and FRONT PANEL must be removed by unscrewing the 6 fixing screws in the lower part of the FRONT PANEL.

INSTALLATION OF EXTERIOR FRAME:





- Assemble the FILTER-STOPPER crossbar and secure the front panel, re-screwing the 6 screws previously removed from the lower part of the panel.

INSTALLATION OF LOWER GRILL:




- Close the grill by turning it until the upper teeth are locked in.





- Extract the filters in an outward horizontal direction and carry out the cleaning operations in accordance with the maintenance instructions supplied with the device;



Re-install the FILTER-STOPPER crossbar, securing it with the 2 screws previously removed in order to guarantee the safety of the device.

- Close the grill again by turning it until the upper teeth are locked in.